

1.The printer must be turned on and connected to the computer via a USB data cable.


2. Double-click to install and open the driver software




3.Confirm that the printer is set to the 58/80mm specification, and follow the steps shown in the screenshot to install it.




4.Check the USB port. It is usually a PID 5720 printer.



5.Install the driver



6.After the installation is completed, send out the print test page. The printer automatically prints the computer test page and the driver installation is complete. The data is issued according to the actual driver number for printing, such as MP-POS80.


MP-POS80 2 Properties
General
Sharing
Ports
Advanced
Color Management
Security
Device Settings
MP-POS80 2
Location:
Comment:
Model:
MP-POS80
Features
Color: No
Double-sided: No
Staple: No
Speed: Unknown
Maximum resolution: 203 dpi
Paper available:
MP-80(72)x3276mm
Preferences...
Print Test Page
OK
Cancel
Apply